

Assembly Instructions



Art No. CJ-OT-305/365/430

2 Outdoor Trampoline

Content

1	GENERAL INFORMATION	8
1.1	Technical Data	8
1.2	Personal Safety	9
1.3	Installation Location	10
2	ASSEMBLY	11
2.1	General Instructions	11
2.2	Assembly of the trampoline	12
2.2.1	Package contents	12
	Assembly Instructions	13
2.3	Assembly of the safety net	17
2.3.1	Package contents	17
2.3.2	Assembly Instructions	18
2.4	Assembly of the ladder	21
3	TRANSPORT AND STORAGE	22
3.1	General Instructions	22
4	TROUBLESHOOTING, CARE AND MAINTENANCE	23
4.1	General Instructions	23
4.2	Maintenance and Inspection Calendar	23
5	DISPOSAL	24
6	RECOMMENDED ACCESSORIES	25
7	ORDERING SPARE PARTS	26
7.1	Serial Number and Model Name	26
7.2	Parts List	27
7.3	Exploded Drawing	28
		20
8	WARRANTY	30
0	CONTACT	22
9	CONTACT	32

4 Outdoor Trampoline

Dear customer,

with a cardiojump trampoline you have made an excellent choice and we thank you for your trust and decision. With cardiojump we offer you high quality trampolines for indoor or garden use. Let your children play outside or do a very effective fitness training in your home, which is easy on the joints. Whatever you want to do, you can rely on your cardiojump trampoline! We wish you lots of fun!

Further information can be found at www.fitshop.com.

Intended Use

The equipment may only be used for its intended purpose.

The equipment is only suitable for home use outdoor. The equipment is not suitable for semiprofessional (e.g. hospitals, associations, hotels, schools, etc.) and commercial or professional use (e.g. fitness studios).

Legal Notice

Fitshop GmbH Europe's No. 1 for home fitness

International Headquarters Flensburger Straße 55 24837 Schleswig Germany Management: Christian Grau Sebastian Campmann Dr. Bernhard Schenkel No. HRB 1000 SL Local Court Flensburg European VAT Number: DE813211547

Disclaimer

© cardiojump is a registered brand of the company Fitshop GmbH. All rights reserved. Any use of this trademark without the explicit written permission of Fitshop is prohibited.

Product and manual are subject to change. Technical data can be changed without advance notice.



ABOUT THIS MANUAL

Please carefully read the entire manual before installation and first use. The manual will help you to quickly set up the system and explains how to safely use it. Make sure that all persons exercising with the equipment (especially children and persons with physical, sensory, mental or motor disabilities) are informed about this manual and its contents in advance. In case of doubt, responsible persons must supervise the use of the equipment.

Due to ongoing changes and software optimisations, the manual may have to be updated. If you notice any discrepancies during assembly or use, please refer to the manual uploaded to the webshop. The latest manual is always available there.



This equipment has been manufactured according to the latest safety knowledge. As far as possible, potential safety hazards which could cause injury have been eliminated. Make sure to carefully follow the instructions and that all parts are securely in place. If required, read through the instructions again to correct any mistakes.

Training devices must be classified according to accuracy and use. Accuracy classes are only applicable to devices that display training data.

Accuracy classes

Class A: high accuracy. Class B: medium accuracy. Class C: low accuracy.

The use classes explain the intended use of the training device.

Use classes

Class S (studio): professional and/or commercial use.

These training devices are intended for the use in training rooms of facilities such as sports clubs, school facilities, hotels, clubs and studios whose access and supervision is specifically regulated by the owner (person with legal responsibility).

Class H (home use): use at home.

These stationary training devices are intended for the use in private homes where access to the training device is regulated by the owner (person with legal responsibility).

Outdoor **Trampoline**



Please pay close attention to the safety and maintenance instructions given here. The contract partner cannot be held liable for damage to health, accidents or damage to the equipment when it is not used in accordance with these instructions.

The following safety instructions may appear in this manual:

► ATTENTION

This notice indicates potentially hazardous situations which, if not avoided, may result in property damage.

This notice indicates potentially hazardous situations which, if not avoided, may result in slight or minor injuries!

MARNING

This notice indicates potentially hazardous situations which, if not avoided, may result in death or serious injuries!

DANGER

This notice indicates potentially hazardous situations which, if not avoided, will result in death or serious injuries!

(i) NOTICE

This notice indicates further useful information.

Retain these instructions in a safe place for future reference, maintenance or when ordering replacement parts.

1.1 Technical Data

Weight and dimensions:

Article weight (gross, excl. packaging): Ø 305cm: 43 kg Ø 365cm: 60.5 kg Ø 430cm: 69 kg

Height inclusive safety net: Ø 305cm | H 253cm Ø 365cm | H 274cm Ø 430cm | H 274cm

Maximum user weight: Ø 305 & 365 cm: 100kg / Ø 430cm: 120 kg

1.2 Personal Safety

A DANGER

- + The trampoline is not suitable for use by children under the age of 6.
- + Children of 6 years and older can only use the trampoline under adult supervision.
- + Never jump onto the trampoline from other objects, e.g. from a roof.
- + Before you start using the trampoline, you should consult your physician that this type of exercise is suitable for you from a health perspective. Particularly are persons who: have a hereditary disposition to high blood pressure or heart disease, are over the age of 45, smoke, have high cholesterol values and/or are overweight.
- + Do not do any summersaults or flips on the trampoline. An incorrect landing on the head or neck can lead to injuries, e.g. paralysis.
- + If you notice any signs of weakness, nausea, dizziness, pain, shortness of breath, or other abnormal symptoms, stop exercising immediately and consult your doctor.

MARNING

- + The trampoline shouldn't be used by more than one person at the same time as there is a high danger of colliding with one another, leading to injuries.
- + Children should not be unsupervised when they are around the trampoline.
- + Please familiarise yourself with the trampoline before use. Please seek advice from a specialist on the proper use of this product.
- + The trampoline cannot be used when the jumping mat is wet or dirty.
- + No eating or drinking allowed while using the trampoline.
- + No smoking allowed while using the trampoline.
- + Do not use the trampoline under the influence of drugs and alcohol.
- + Free your hands and pockets from objects before using the trampoline.
- + Always jump in the middle of the trampoline. Jumping purposely aginst the safety net, frame covers or on the springs can lead to injuries.
- + Safely secure the trampoline from unauthorised use, e.g. from small children!
- + Make sure that the opening of the safety net is closed before each use.
- + Keep your hands, feet and other body parts, hair, clothing, jewellery and other objects well clear of moving parts.
- + Before using the trampoline please take off jewellery and similar items.
- + Before each use of the trampoline please check that nothing is underneath the jumping mat.

- + The equipment may only be used for its intended purpose.
- + Every other usage is prohibited and potentially dangerous. The manufacturer/retailer will not be held responsible for damages resulting from incorrect usage or usage not for its intended purpose.
- + Wear suitable clothing while using the trampoline. We recommend primarily sports clothing and socks. Do not wear shoes while using the trampoline! Inspect your clothing so that no objects, e.g. small hooks, can get tangled with the safety net.
- + Enter and exit the trampoline only by climbing through the opening of the safety net.
- + Do not climb on the safety net or up the safety poles.
- + Learn the basics of jumping on a trampoline before attempting advanced manoeuvres.
- + Inspect the trampoline before each use for signs of wear, defects or missing pieces.
- + Avoid from jumping too high. Always stay in contol over your jumps.

ATTENTION

- + Remove all pointed and sharps objects on and around the trampoline before usage.
- + Avoid having open fires near the trampoline, don't place a barbecue in the immediate vicinity of the trampoline.
- + The opening of the trampoline must be kept free of foreign objects.

1.3 Installation Location

\land WARNING

- + A safety area of at least 7m above the trampoline, measured from the ground), must be clear. Also the trampoline should not be placed in main passageways or escape routes.
- + Choose a location in which there is enough free space/clearance, of at least 2m, to the front, rear and sides of the trampoline.

+ Make sure that the trampoline is flat and even on the ground.

2.1 General Instructions

<u>Μ</u> DANGER

+ Do not leave any tools, packaging materials such as foils or small parts lying around, as otherwise there is a danger of suffocation for children. Keep children away from the equipment during assembly.

/ WARNING

- + The assembly and usage of the trampoline should not be undertaken duing wind, rain and storms, also especially with thunder! We recommend that in these conditions that the trampoline should be secured, e.g. with earth anchors. In extreme weather conditions (severe storm) we recommend further securing the trampoline or, at best, to dismantle the trampoline.
- + Pay attention to the instructions attached to the equipment in order to reduce the risk of injuries.

- + Do not open the packaging when it is lying on its side.
- + Ensure you have sufficient room for movement in each direction during assembly.
- + The assembly of the equipment must be carried out by at least two adults. If in doubt, seek the help of a third technically skilled person.

ATTENTION

+ To prevent damage to the equipment and the floor, assemble the equipment on a mat or on top of the packaging.

i NOTICE

- + Some of the pieces used could already be pre-assembled, so that assembly is as simple as possible and to save on packaging materials.
- + Ideally the assembly should take place at the installation location.
- + To guaranty a long lasting safety level, we recommend getting the trampoline regulary serviced (once a year) from specialists (Sport-Tiedje service technicians).

2.2 Assembly of the trampoline

2.2.1 Package contents

The package contents consists of the following illustrated parts. Check that all parts of the package contents have been delivered. Should a part be missing or transport damages are discovered, please immeadiately contact your contract partner.

(i) NOTICE

For the assembly of the safety net, a spanner and a screwdriver are required. These are not included in the package contents.



1	Jumping mat
2	Protection ring
3	Upper frame with leg insert
4	Feet
5	Frame connectors
6	Springs
7	Screws
8	Spring tensioner tool
9	Rope

2.2.2 Assembly Instructions

Before assembly, take a close look at the individual assembly steps shown and carry out the assembly in the order given.

(i) NOTICE

- + First loosely screw all parts together and check that they fit properly. Tighten the screws using the tool only when you are instructed to do so.
- + If you have difficulty recognising the graphics, we recommend that you open and/or download the PDF instructions stored in the webshop on your end device (e.g. smartphone, tablet or PC). There you have the option of zooming in closer. Please note that the Adobe Acrobat Reader programme must be installed on your end device in order to open the file.

365cm and 430cm (4 legs)



305cm (3 Legs)

(i) NOTICE

Please note that the trampoline in size 305cm only has three legs when compared to the other sizes.

i NOTICE

The assembly of this trampoline should be carried out by at least two adults!

Step 1:

Insert the frame connectors (5) with the feet (4).



Step 2:

- Connect two of the upper frame with leg Inserts
 (3) together.
- 2. Stand up the constructed frame from step 1.
- 3. Insert the pieces of the upper frame (3) onto the frame connectors (5).



Step 3:

Once you've connected all the pieces together in step 2 (see fig. 5), connect the constructed pieces together as pictured in fig. 6.



Step 4:

Lay the jumping mat (1) in the middle of the constructed frame (see figure).



Step 5:

MARNING:

Crushing hazard!

While attaching the springs, please take care NOT to grip the springs with your hand and only to utilise the spring tensioner tool. While releasing the tension it could lead to crushing between the springs.

1. Hang one end of the spring in one of the loops of the jumping mat.





2. Pull with the spring tensioning tool towards the frame.

3. Hook the other end of the spring, with the spring tensioning tool, into the corresponding hole in the frame.

4. With the spring tensioning tool, place the springs in the order shown in the following

table and figure. The number correspondes to the respective loop on the jumping mat. The springs are approximately placed in quarters, using the spring tensioning tool, from each other.



Trampoline	#A	#B	#C	#D
305cm	1	14	28	42
365cm	1	18	36	54
430cm	1	22	44	66

Step 6:

Fasten the protection ring onto the frame as pictured. Fasten the protection ring onto the jumping mat with help of the rope (9) as picutred.



2.3 Assembly of the safety net

2.3.1 Package contents

The package contents consists of the following illustrated parts and tools. Check that all parts of the package contents have been delivered. Should a part be missing or transport damages are discovered, please immeadiately contact your contract partner.

(i) NOTICE

For the assembly of the safety net, a spanner and a screwdriver are required. These are not included in the package contents.



1	Pole A for the safety net.
2	Pole B for the safety net
3	Spacer
4	Curved washer
5	Screws
6	Nuts
7	Safety net

2.3.2 Assembly Instructions

Before assembly, take a close look at the individual assembly steps shown and carry out the assembly in the order given.

(i) NOTICE

The assembly of this safety net should be carried out by at least two adults!

Step 1:

Insert Pole A of the safety net (1) into Pole B of the safey net (2).



Step 2:

- 1. Mount the construction from step 1 onto the assembled trampoline, each with two spacers (3), two curved washers (4), two screws (5) and two nuts (6) (see, fig. A1 & A2).
- 2. Tighten the screws with a screw drive and spanner.



Step 3:

Place the entry/exit of the safety net in the desired position. Once positioned pull the loops over the knobs on the end of the poles (see figure).



Step 4:

Fasten the safety net by pulling the loops over the hooks of the springs (see figures).





(i) NOTICE

Fasten the safety net going in one direction only.



(i) NOTICE

Once finished please check to see if all screws and connections are properly tightened.



2.4 Assembly of the ladder

(i) NOTICE

Dependant on the model, the number of rungs and screws can vary.

Step 1:

Place the rung between the two rails as pictured.



Step 2:

Fasten the rungs, each with two screws, two curved washers and two nuts, onto the rails (see figure).



Step 3:

Hang the ladder on the frame of the trampoline.



3.1 General Instructions

MARNING

+ The storage location should be chosen so that improper use by third parties or children can be prevented.

+ Should you want to move the trampoline, lift the trampoline with at least one other adult. Lift at the connection points and carry it to the desired location. Slowly place the trampoline back onto the ground. The new location should take into account the recommendations stated in section 1.3. in this manual. For longer distances, the trampoline should be disassembled for transport.

ATTENTION

+ Make sure that the trampoline is protected from moisture, dust and dirt in the selected storage location. The storage location should be dry and well ventilated and have a constant ambient temperature between 5°C and 45°C.

4.1 General Instructions

+ Do not make any improper changes to the trampoline and its accessories.

▲ CAUTION

+ Damaged or worn components may affect your safety and the life of the trampoline. Therefore, immediately replace damaged or worn components. In such a case, contact your contract partner. The trampoline can not be used until it has been repaired. When possible, use only original spare parts.

► ATTENTION

+ In addition to the instructions and recommendations for maintenance and care given here, additional service and/or repair work may be necessary; this must only be carried out by authorised service technicians.

4.2 Maintenance and Inspection Calendar

To avoid damage from body sweat, the trampoline must be cleaned with a damp towel (no solvents!) after each training session.

Part	Weekly	Monthly	Quarterly	Half-yearly	Yearly	
Jumping mat and springs		I/C				
Frame		I/C				
Frame padding		I/C				
Screw connections		Ι				
Insert connections		I				
Legend: I = Inspect, C = Cle	Legend: I = Inspect, C = Clean					

The following routine tasks must be performed at the specified intervals:



At the end of its operational life, this equipment cannot be disposed of in normal household waste. Instead, it must be disposed of via an electricals recycling centre. Further information can be obtained from your local authority's recycling service.



The materials can be recycled as per their symbols. Through the reuse, recycling of materials or other forms of recovery of old equipment, you make an important contribution to the protection of the environment.

25

6 RECOMMENDED ACCESSORIES

To make your training experience even more efficient and pleasant, we recommend that you add suiting accessories to your fitness equipment. This could be a **floor mat**, for example, which makes your fitness equipment stand more securely and also protects the floor from falling sweat, but it could also be additional handrails on some treadmills or **silicone spray** to keep moving parts in good shape.

If you have purchased a fitness machine with pulse training and want to train your heart rate, we strongly recommend that you use a compatible chest strap, as this ensures optimum transmission of the heart rate. You may want to buy additional **grips** or **weights** for multi gyms.

Our range of accessories offers the highest quality and makes training even better. If you would like to find out more about compatible accessories, please go to the detail page of the product in our webshop

(the easiest way is to enter the article number in the search field above) and go to the recommended accessories on this page. Alternatively, you can use the QR code provided. Of course, you can also contact our customer service: by telephone, e-mail, in one of our branches or via our social media channels. We will be happy to advise you!





7.1 Serial Number and Model Name

In order to provide you with the best possible service, please have the model name, article number, serial number, exploded drawing and parts list ready. The corresponding contact options can be found in chapter 9 of this operating manual.

Outdoor Trampoline

(i) NOTICE

The serial number of your equipment is unique. It's located on a white sticker.

Enter the serial number in the appropriate field.

Serial number:

Brand / Category:

cardiojump / outdoor trampoline

Model Name:

OT-305/365/430

Article Number:

CJ-OT-305/365/430



7.2 Parts List

Trampoline

No.	Name	Qty.	10′	12′	14′
1	Trampoline Mat, stitched with V-Rings	Pcs	1	1	1
2	Frame Pad	Pcs	1	1	1
3	Top Rail with leg sockets	Pcs	6	8	8
4	Leg Base	Pcs	3	4	4
5	Vertical Leg Extension	Pcs	6	8	8
6	Springs	Pcs	54	72	88
7	Screw for leg	Pcs	6	8	8
8	spring tool	Pcs	1	1	1
9	Ropes	Pcs	2	2	2

Safety Net

No.	Name	Qty.	10′	12′	14′
1	Upper pole A	Pcs	6	8	8
2	Upper pole B	Pcs	6	8	8
3	Bar Spacers	Pcs	12	16	16
4	Curved Washers	Pcs	12	16	16
5	Screws	Pcs	12	16	16
6	Nuts	Pcs	12	16	16
7	Safety Net	Pcs	1	1	1

Ladder

No.	Name	Qty.	10′	12′+14′
LD001	Frame poles	Pcs	2	2
LD002	Step poles	Pcs	2	3
LD003	Screws	Pcs	4	6
LD004	Curved Washers	Pcs	4	6
LD005	Nuts	Pcs	4	6

7.3 Exploded Drawing



28



8 WARRANTY

Products from cardiojump[®] are subject to strict quality control. However, if a fitness equipment purchased from us does not work perfectly, we take it very seriously and ask you to contact our customer service as indicated. We are happy to help you by phone via our service hotline.

Error Descriptions

Your fitness equipment is developed for long-term, high-quality training. However, should a problem arise, please first read the operating instructions. For further assistance, please contact your contract partner or call our service hotline. To ensure your problem is solved as quickly as possible, please describe the defect as exactly as possible.

In addition to the statutory warranty, we provide a warranty for every fitness equipment purchased from us according to the following provisions.

Your statutory rights are not affected.

Warrantee

The warrantee is the first/original buyer and/or any person who received a newly purchased product as a gift from the original buyer.

Warranty period

The warranty periods, shown on our web shop, begin on delivery of the fitness equipment. The respective warranty periods for your equipment can be found on its product website.

Repair Costs

According to our choice, there will either be a repair, a replacement of individual damaged parts or a complete replacement. Spare parts, that have to be mounted while assembling the equipment, have to be replaced by the warrantee personally and are not a part of repair. After the expiration of the warranty period, the responsibility for parts costs, repair costs, installation costs and delivery costs lies with the warranty holder.

The terms of use are defined as follows:

- + Home use: solely for private use in private households up to 3 hours per day
- + Semi-professional use: up to 6 hours per day (e. g. rehabilitation centres, hotels, clubs, company gyms)

Outdoor **Trampoline**

+ Professional use: more than 6 hours per day (e. g. commercial gyms)

Warranty Service

Within the warranty period, equipment which develops faults as a result of material or manufacturing defects, will be repaired or replaced at our discretion. Ownership of equipment or parts of equipment which have been replaced is transferred to us. The warranty period is not extended nor does a new warranty period begin following repair or replacement under the warranty.

Warranty Conditions

For the warranty to be valid, the following steps must be taken:

Please contact our customer service by email or phone. If the product under warranty has to be sent in for repair, the seller bears costs. After expiry of the warranty, the buyer bears the costs of transport and insurance. If the fault is covered by our warranty, you will receive a new or repaired equipment in return.

Warranty claims are invalid in case of damage resulting from:

- + misuse or improper handling
- + environmental influences (moisture, heat, electrical surge, dust, etc.)
- + failure to follow the current safety measures for the equipment
- + failure to follow the operating instructions
- + use of force (e.g. hitting, kicking, falling)
- + interventions which were not carried out by one of our authorized service centres
- + unauthorised repair attempts

Proof of Purchase and Serial Number

Please make sure that you are able to provide the appropriate receipt when claiming on your warranty. So that we can clearly identify the model of your equipment, and for the purposes of our quality control, you will need to give the serial number of your equipment, when contacting the service team. Where possible please have your serial number and your customer number ready when you call our service hotline. It will help us to deal with your request swiftly.

If you cannot find the serial number on your fitness equipment, our service team is at your disposal to offer further information.

Service outside of the Warranty Period

We are also happy to issue an individual cost estimate if there is a problem with your fitness equipment after the warranty has expired, or in cases which do not fall under the terms of the warranty, e.g. normal wear and tear. Please contact our customer service team to find a quick and cost-effective solution to your problem. In such a case you will be responsible for the delivery costs.

Communication

Many problems can be solved just by speaking to us as your specialist supplier. We know how important it is to you as a user of the fitness equipment to have problems solved quickly and simply, so you can enjoy working out with minimal interruption. For that reason, we also want to resolve your queries quickly and in a straightforward manner. Thus, please always keep your customer number and the serial number of the faulty equipment handy.



DE	DK	UK
ТЕСНИК	TEKNIK OG SERVICE	CUSTOMER SUPPORT
 ↓49 4621 4210-900 ↓49 4621 4210-698 ☑ technik@fitshop.de Offnungszeiten entnehmen Sie unserer Homepage. SERVICE ♦ 0800 20 20277 (kostenlos) 	 80 90 16 50 +49 4621 4210-945 info@fitshop.dk Åbningstider kan findes på hjemmesiden: https://stg.fit/statit7 FR TECHNIQUE & SERVICE	 Construction Soft Formation Construction Soft Formation Soft Format
 04621 4210 - 0 info@fitshop.de Öffnungszeiten entnehmen Sie unserer Homepage: https://stg.fit/statita 	 +33 (0) 189 530984 +49 4621 42 10 933 info@fitshop.fr Vous trouverez les heures d'ouverture sur notre site Internet: https://stg.fit/statit4 	 02 732 46 77 +49 4621 4210 933 info@fitshop.be Vous trouverez les heures d'ouverture sur notre site Internet: https://stg.fit/statit8
ES	NL	INT
 TECNOLOGÍA Y SERVICIOS ♀ 911 238 029 info@fitshop.es Consulta nuestro horario de apertura en la página web: https://stg.fit/statit5 	 TECHNISCHE DIENST & SERVICE ↔ +31 172 619961 iservice@fitshop.nl De openingstijden vindt u op onze homepage: https://stg.fit/statit3 	 TECHNICAL SUPPORT & SERVICE ↔ +49 4621 4210-944 is service-int@fitshop.de You can find the opening hours on our homepage: https://stg.fit/statita
PL	AT	СН
DZIAŁ TECHNICZNY I SERWIS 22 307 43 21 +49 4621 42 10-948 info@fitshop.pl Godziny otwarcia można znaleźć na stronie głównej: https://stg.fit/statit6	TECHNIK & SERVICE ♦ 0800 20 20277 (Freecall) +49 4621 42 10-0 ■ info@fitshop.at ♦ Öffnungszeiten entnehmen Sie unserer Homepage: https://stg.fit/statitb	TECHNIK & SERVICE ♦ 0800 202 027 +49 4621 42 10-0 ■ info@fitshop.ch ♦ Öffnungszeiten entnehmen Sie unserer Homepage: https://stg.fit/statit9

Please find a detailed overview including address and opening hours for all stores of the Fitshop Group in Germany and abroad on the following website:

www.fitshop.com/en/stores

WE LIVE FITNESS

WEBSHOP AND SOCIAL MEDIA

Fitshop is Europe's largest specialist store for home fitness equipment with currently over 70 stores and one of the world's most renowned online mail order companies for fitness equipment. Private customers order via the 25 web shops in the respective national language or have their desired equpiment assembled on site. In addition, the company supplies fitness studios, hotels, sports clubs, companies and physio practices with professional equipment for endurance and strength training.

Fitshop offers a wide range of fitness equipment from renowned manufacturers, high-quality in-house developments and comprehensive services, such as a build-up service and sports scientific advice before and after the purchase. The company employs numerous sports scientists, fitness trainers and competitive athletes.

Visit us also on our social media platforms or our blog!





Outdoor Trampoline



