




Model # FTX.2PK

USER MANUAL

FTX | FUNCTIONAL TRAINER



Record Serial Number Here

Health in Motion LLC
V08102022

CONGRATULATIONS

You've just taken the first step to a healthier and stronger body. This functional trainer by Inspire offers the key to unlocking your body's potential. Regular strength training on a functional trainer has been shown to deliver a host of benefits including: increased muscle tone, decreased body fat, improved energy levels, a reduction in stress, and improved cardiac output. Once again, congratulations, you are on your way to improving your self image, overall health, and quality of life.

BEFORE ASSEMBLING YOUR HOME GYM

IMPORTANT: Read this entire manual before attempting to build or use this machine. This manual contains step by step instructions for proper assembly.

Use the parts list included in this manual to verify that all parts are accounted for before assembly. If any parts are missing, contact the retailer of this functional trainer for replacement parts. Or, call Inspire at 877-738-1729.

functional trainer to protect wood flooring or carpeting from damage during assembly and usage.

This functional trainer is intended for indoor use only. Rust can form on certain parts including guide rods in a humid environment, resulting in impaired function.

Service of your functional trainer should only be performed by an authorized Inspire retailer. Service performed by anyone else can result in loss of warranty. **Support is provided in English and Spanish.** If you need help finding an authorized retailer, please contact us directly:



Email

service@inspirefitness.com



Phone

877-738-1729 (US Only)

+1 714-738-1729 (International)

Mon-Fri 8am-5pm PT - UTC-7h/8h



Chat

www.inspirefitness.com

Support is provided in English and Spanish

PRODUCT WARRANTY

To view full warranty details, or to register your product for warranty, visit [inspirefitness.com/support](https://www.inspirefitness.com/support)

TABLE OF CONTENTS

IMPORTANT SAFETY NOTICE5

HARDWARE SIZING CHART.....6

FUNCTIONAL TRAINER ASSEMBLY INSTRUCTIONS.....8

DECAL PLACEMENT.....12

MAINTENANCE.....13

MAINTENANCE SCHEDULE.....13

PARTS LIST.....15

FLB2C USER MANUAL.....16

IMPORTANT SAFETY NOTICE

PRECAUTIONS


This exercise machine is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble or operate your machine. Please note the following safety precautions:

1. Always keep children and pets away from the machine. DO NOT leave children unattended in the same room with the machine. The cabling and moving parts on this machine can cause serious injury or death if used improperly.
2. Only one person at a time should use the machine.
3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. CONSULT A PHYSICIAN IMMEDIATELY.
4. Position the machine on a clear, leveled surface. DO NOT use the machine near water or outdoors.
5. Keep hands away from all moving parts.
6. Always wear appropriate workout clothing when exercising. DO NOT wear robes or other loose clothing that could become caught in the machine. Running or training shoes are also required when using the machine.
7. Use the machine only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
8. Do not place any sharp objects around the machine.
9. Disabled persons should not use the machine without a qualified person or physician in attendance.
10. Before using the machine to exercise, always do stretching exercises to properly warm up.
11. Never operate the machine if the machine is not functioning properly.

Care and Maintenance

- Inspect and tighten all parts before using the machine.
- The Frame and Seat Pad of the machine can be cleaned using a damp cloth and mild non-abrasive detergent. DO NOT use solvents.


WARNING: BEFORE BEGINNING ANY EXERCISE PROGRAM, CONSULT YOUR PHYSICIAN. THIS IS ESPECIALLY IMPORTANT FOR INDIVIDUALS OVER THE AGE OF 35 OR PERSONS WITH PRE-EXISTING HEALTH PROBLEMS. READ ALL INSTRUCTIONS BEFORE USING ANY FITNESS EQUIPMENT. Health In Motion, LLC. DOES NOT ASSUME ANY RESPONSIBILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE SUSTAINED BY OR THROUGH THE USE OF THIS PRODUCT.



FUNCTIONAL TRAINER ASSEMBLY INSTRUCTIONS


STEP 1

- A. Do not tighten the Nuts and Bolts until instructed to do so.
- B. Place the Lower Cross Brace (#4) between the Right & Left Stations (#1 & #2) in the mid-span.
- C. Attach one end of the Lower Cross Brace to the Right Station. Secure it with two M10 x 70 Allen Bolts (#19) four Ø 10 Washers (#25), and two M10 Aircraft Nuts (#24). Repeat the same procedure to install the other side.
- D. Repeat Procedure **B & C** to install the Upper Cross Brace (#5).
- E. Place the Pull Up Bar Assembly (#3) on top of the Right and Left Stations.
- F. Secure each end with two M10 x 25 Allen Bolts (#20), two Ø 10 " Lock Washers (#23), and Ø 10 Washers (#25).
- G. Place the Tablet Holder on to its mount and secure with a M6x75mm Allen Head Cap Screw (#28) and M6 Locknut (#30), using M6 Washers (#29) on both sides. Tighten hardware until tablet holder holds its position but can still be tilted up and down by hand.
- H. Securely tighten all Nuts and Bolts installed.







STEP 2

- A. Install Guide Rods (#7) into holes on bottom Frame using M10 x 80 Allen Bolt (#18) and Ø 10 Spring Washers (#25). Tighten.
- B. Install Rubber Bumpers (#16) on each Guide Rod (#7). Slide fifteen 10lb Weight Plates (#10) from the top of Guide Rods (#7) down to the Rubber Bumpers (#16). Make sure the weight sticker cut out is facing the inside of the machine and the pads of the weight face down. See example below:





- C. Remove the two M10 x 20 Allen Bolts (#21), Ø 10 Spring Washers (#23), and Ø 10 Washers (#25) which were pre-assembled in the factory to hold the Guide Rod Bracket (#6). Slide the Selector Stem Assembly (#8) onto the Guide Rods (#7). Install the weight stack Pulley (#33) with the cable wrapped between the pulley and the U shaped bracket (#31). Then insert the Cam Bolt (#32) and secure with a Ø 10 Washer (#25), and a M10 Aircraft Nut (#24).
- D. Hold the Selector Stem Assembly (#8) above the weight stack to make it easier to install Guide Rod Bracket (#6) on Guide Rods (#7).
- E. Once the Guide Rod Bracket (#6) is installed onto the Guide Rods (#7), Push the Guide Rod Bracket back into the upright.
- F. Secure the Bracket back to the upright frame with the two M10 x 21 Allen Bolts (#21), Ø 10 lock Washers (#23), Ø 10mm Washers (#25).
- G. Lower the Selector Stem down onto the top of the weight stack.
- H. Check all the cables to make sure they are on track on the pulleys.
- I. Peel off the weight stack number label from the Resistance Label Set (#26) and attach to the plates, starting with number one on the selector stem weight.
- J. Insert the Weight Selector Pin (#9) into the weight stack.
- K. Lubricate the Guide Rods with super lube or lube provided in Hardware Pack.
- L. If Needed, Adjust the cable tension by loosening and rotating the Cam Bolt (#32) until the Selector Stem Assembly (#8) starts lifting slightly from the weight stack. Tighten the nut of the cam bolt to lock it's position.
- M. **Repeat the Procedure A through L** above to install the other set of weight plates to the Left Station. (#2)



STEP 3

- A. Attach the Height Adjustment Handle (#15) to the Left Lock Switch (#35) on the Pulley Carriage, secure it with one M5 x 10 Allen Bolt (#22). Repeat the same procedure to install the other side.
- B. Connect the Single Handle (#13) to the Cable (#1) on the Right Station (#1) with a Spring Clip (#17). Repeat the same procedure to install the other side.
- C. Lift up the Height Adjustment Handle (#15) and slide the Pulley Carriage along the Pulley Carriage Support Frame to the selected level. Release the Handle to lock the Pulley Carriage in position.
- D. Store Curl Bar (#12), and Rope (#11) onto the Hanger Bracket behind the Upper Cross Brace (#5). Hang Chin Up Belt (#14) on Upper Cross Brace (#5).



MAINTENANCE

Warning

DO NOT place styrofoam or printed materials on the seat pads. Over time, these may stick to the pads and mar the surface.


DO NOT leave items sitting on the seat pads, these pads have a special density that takes shape to objects and small objects will leave imprints in the surface that may take time to come out.

- Periodically inspect the cables for splitting, cracking or fraying. Also watch for bulging or flat areas in the cable.
- Immediately replace cables at the first signs of damage or wear. Never use equipment with damaged or worn cables.
- Cables naturally stretch over time, so check cable slack periodically and adjust cable tension as needed.
- Regularly inspect product for loose hardware.
- Do not use or store equipment outdoors.
- Inspect snap links, swivels, handles and weight stack pin for wear or damage. If wear or damage exists, replace with Inspire Fitness parts only.
- Locate and familiarize yourself with all warning decals on the Smith Machine Functional Trainer.
- Replace damaged or worn upholstery immediately.
- Periodically wipe down guide rods with a dry cloth and re-apply a thin coat of a Teflon™ based lubricant.

MAINTENANCE SCHEDULE

ROUTINE	HOME MAINTENANCE	ENTRY DATE																		
Inspect: Links, Pull Pins, Spring Clips, Swivels, Weight Stack Pins	WEEKLY																			
Clean: Upholstery	WEEKLY																			
Inspect: Cables and their Fittings	WEEKLY																			
Inspect: Tautness of all Shrouds	WEEKLY																			
Inspect: Accessory Bars and Handles	3 MONTHS																			
Inspect: All Decals	3 MONTHS																			
Inspect: All Nuts and Bolts. Tighten if Needed	3 MONTHS																			
Inspect: Anti-Skid surfaces	3 MONTHS																			
Clean and Lubricate: Guide Rods with a Teflon based lubricant	3 MONTHS																			
Lubricate: Seat Sleeves and all Plastic Slides	3 MONTHS																			
Clean and Wax: All Glossy Finishes	YEARLY																			
Replace: Cables, Belts and Connecting Parts	2 YEARS																			

EXPLODED DIAGRAM



PARTS LIST

No.	Description	Part Number	Qty.
1	Right Station Assembly	100100	1
2	Left Station Assembly	100101	1
3	Upper Frame Assembly	100104	1
4	Lower Cross Brace	100102	1
5	Upper Cross Brace	100103	1
6	Guide Rod Bracket	100185	2
7	Guide rod	100122	4
8	Selector Stem Assembly	100183	2
9	Weight Selector Pin	100151	2
10	Weight Plate	100177	30
11	Rope	100172	1
12	Curl Bar	100184	1
13	Single Handle	100152	2
14	Chin Up Belt	100171	1
15	Height Adjustment Handle	100145	2
16	Rubber Bumper	100148	4
17	Hook	100174	2
18	M10×80 Allen Bolt	100187	6
19	M10×70 Allen Bolt	100188	8
20	M10×25 Allen Bolt	100189	4
21	M10×20 Allen Bolt	100190	6
22	M5×10 Allen Bolt	100191	2
23	φ10 Lock Washer	100192	10
24	M10 Aircraft Nut	100193	28
25	φ10 Washer	100194	62
26	Resistance Label Set	100178	2
27	Tablet Holder	100186	1
28	M6×75 Bolt	100195	1
29	φ6 Washer	100196	2
30	M6 Aircraft Nut	100197	1
31	Pulley Bracket	100110	2
32	Cam Bolt	100115	2
33	Pulley	100173	16
34	Right Lock Switch	100108	1
35	Left Lock Switch	100109	1
36	Guide Rod	100134	2
37	Fixing Sleeve of Guide Rod	100147	4
38	Big End Cap	100150	4
39	End Cap	100149	2
40	Square End Cap	100175	4
41	Cable combination	100170	2
42	U-shaped Connecting plate	100121	2
43	Anti-slip Plate	100116	6
44	Cover Plate	100114	4
45	Right Gear Frame	100118	1
46	Left Gear Frame	100119	1
47	Slider	100105	2
48	Sleeve	100139	4
49	Sleeve	100138	4

No.	Description	Part Number	Qty.
50	Bushing	100143	4
51	Bushing	100144	4
52	Sliding Frame	100106	2
53	Double Pulley Frame	100107	2
54	Slider	100135	4
55	Pop Pin Pivot	100123	2
56	Spring	100153	2
57	E-shaped Ring	100198	2
58	C-shaped Ring	100199	4
59	Adjustment Plate	100120	2
60	Rotating Bracket	100112	2
61	Anti-slip Pad	100124	2
62	End Cap	100140	2
63	End Cover	100141	2
64	Spacer	100142	2
65	M10×45 Allen Bolt	100200	2
66	M10×50 Allen Bolt	100201	8
67	M10×60 Allen Bolt	100202	4
68	M10×45 Allen Bolt	100203	4
69	M12×80 Allen Bolt	100204	2
70	M6×16 Allen Bolt	100205	16
71	M4×16 Bolt	100206	4
72	M8×55 Allen Bolt	100207	2
73	M8×20 Allen Bolt	100208	16
74	Special Bolt	100136	2
75	M5×10 Bolt	100209	10
76	φ8 Lock Washer	100210	16
77	φ8 Washer	100211	24
78	M6 Nut	100212	2
79	M12 Nut	100213	2
80	φ12 Washer	100214	4
81	M8 Aircraft Nut	100215	2
82	M4 Aircraft Nut	100216	4
83	M12 Aircraft Nut	100217	2
84	Upper Cover	100161	1
85	Lower Cover	100162	1
86	Front Cover	100163	1
87	Back Cover	100164	1
88	Connecting Board	100165	1
89	Fixing Board	100166	1
90	Panel	100167	1
91	Cushion	100168	2
92	Spring	100169	1
93	Fixing Bracket	100117	1
94	M3×8 Countersunk Head Screw	100218	4
95	ST2.2×6.5 Countersunk Head Tapping Screw	100219	8
96	ST2.2×9.5 Countersunk Head Tapping Screw	100220	7
97	ST2.2×9.5 Pan Head Tapping Screw	100221	4
98	ST2.2×6.5 Pan Head Tapping Screw	100222	4
99	Foot Pad	100146	6
100	ST4.2×12 Pan Head Tapping Screw	100223	12
TOOL LIST			
101	#6 Allen Wrench	100224	1
102	#5 Allen Wrench	100225	1
103	#3 Allen Wrench	100226	1
104	#10 Wrench	100227	1



Model # FLB2

USER MANUAL

FLB2

**FOLDING
ADJUSTABLE
BENCH**



Record Serial Number Here

Health in Motion LLC
V08102022

IMPORTANT SAFETY NOTICE

PRECAUTIONS

This exercise bench is built for optimum safety. However, certain precautions apply whenever you use a piece of exercise equipment. Be sure to read the entire manual before you assemble or use your bench. In particular, note the following safety precautions:

1. Keep children and pets away from the bench at all times.
2. Only one person at a time should use the bench.
3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. Consult a physician.
4. Position the bench on a clear, leveled surface. Do not use outdoors.
5. Keep hands away from all moving parts.
6. Always wear appropriate workout clothing when exercising. Running or aerobic shoes are also required when using the bench.
7. Use the bench only for its intended use as described in this manual.
8. Disabled persons should not use this bench without a qualified person or physician in attendance.
9. Always do stretching exercises to properly warm up before using this bench.
10. Never use this bench if it is not functioning properly.
11. A spotter is recommended during exercise.
12. Maximum **USER** weight on bench is 136 kg / 300 lb. This means that a **PERSONS** maximum weight can be up to 136 kg / 300 lb.
The total weight capacity that the bench can hold is 226.8 kg / 500 lb.

CARE AND MAINTENANCE

1. Regularly inspect product for loose hardware.
2. Do not use or store equipment outdoors.
3. Locate and familiarize yourself with all warning decals on the home gym.
4. Replace damaged or worn upholstery immediately.

BEFORE YOU BEGIN

Thank you for selecting the Inspire Fitness FLB2C. Service of your bench should only be performed by an authorized Inspire retailer. Service performed by anyone else can result in loss of warranty. For your safety and benefit, read this manual carefully before using the machine. As a manufacturer, we are committed to providing you complete customer satisfaction. If you have any questions, or find there are missing or damaged parts, please call our TOLL-FREE customer service number. Our Customer Service agents will provide immediate assistance to you.



Email

costcosupport@inspirefitness.com



Phone

877-738-1729 (US Only)
+1 714-738-1729 (International)
Mon-Fri 8am-5pm PT - UTC-7h/8h



Chat

www.inspirefitness.com

Support is provided in English and Spanish


PRODUCT WARRANTY

To view full warranty details, or to register your product for warranty, visit [inspirefitness.com/support](https://www.inspirefitness.com/support)


AUSTRALIA

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This bench is for adult use only. Do not let children play with the bench. Use caution while adjusting or working out on the bench.



Pull pop pin to unfold or fold leg. Make sure hands are clear of pivot area. Make sure pop pin is fully engaged in locking holes after each adjustment.



Swivel lock lever under pad to release back pad. Raise the head end of the pad so the free end of the support tube slips into a slot for a desired position. Before use, make sure the support tube is secure in a slot.

When folding the bench flat, keep hands clear of any pivot areas or closing areas. make sure the lock lever is locked over catch pin before moving.



www.inspirefitness.com